





# CORREDERAS

## CORREDERA H25

### Guía de Instalación


Formato sin escala

## 2508BZ



CODE/ CÓDIGO	A	B	C	D	E	F	
2508BZ250	9-13/16" / 250mm	9-13/16" / 250mm	-	-	5-9/16" / 142mm	6-1/4" / 158mm	30
2508BZ300	11-13/16" / 300mm	11-13/16" / 300mm	3-3/4" / 96mm	4-7/16" / 112mm	7-9/16" / 192mm	8-3/16" / 208mm	30
2508BZ350	13-3/4" / 350mm	13-3/4" / 350mm	5-1/16" / 128mm	5-1/16" / 128mm	9-7/16" / 240mm	10-1/16" / 256mm	30
2508BZ400	15-3/2" / 400mm	15-3/2" / 400mm	5-1/16" / 128mm	9-1/2" / 242mm	10-11/16" / 272mm	11-5/16" / 288mm	30
2508BZ450	17-11/16" / 450mm	17-11/16" / 450mm	6-5/16" / 160mm	7-9/16" / 192mm	13-1/4" / 336mm	13-7/8" / 352mm	30
2508BZ500	19-11/16" / 500mm	19-11/16" / 500mm	7-9/16" / 192mm	7-9/16" / 192mm	14-1/2" / 368mm	15-1/8" / 384mm	30

#### Space requirement/ Requerimiento de espacio



#### Installation dimensions/ Dimensiones de instalación (mm)

