

# DOOR LOCKS

## LISABON



### Installation Guide

9807

Print at actual size

## INSTRUCTIONS FOR INSTALLATION OF TUBULAR LOCKSETS

INSTALLATION ILLUSTRATIONS ARE SHOWN WITH ENTRY MODELS. PROCEDURE IS IDENTICAL FOR PRIVACY. CLOSET AND EXIT MODELS IN ANY, KNOB DESIGN.

<b>1. MARK DOOR</b>		<b>4. INSTALL STRIKE</b>	
<p><b>A.</b> Start approximately 36" from floor. Fold and apply template to high edge of door bevel and mark center of door edge as indicated on template.</p> <p>HIGH SIZE OF BEVEL</p> <p>MARK FOR 31/32" OR 1" HOLE IN DOOR EDGE</p>	<p><b>B.</b> Mark center hole on door face through guide on template for 2-3/8" (60mm) or 2-3/4" (70mm) backset.</p> <p>MARK FOR 2" OR 2-1/8" HOLE IN DOOR FACE</p>	<p><b>A.</b> Insert end of template against flat of latch bolt and close door against stop. Mark template from edge of jamb and locate strike opening. Move 1/4" for plain latch and 3/4" for deadlatch toward door stop to locate center line for screws and 1" hole.</p> <p>JAMB</p>	<p><b>B.</b> Drill 31/32" or 1" hole 1/2" deep in door jamb on center line of screws. CAUTION To assure proper lockset function hole in jamb must be drilling full 1/2" deep.</p>
<b>2. DRILL HOLES</b>		<b>5. INSTALL EXTERIOR MECHANISM</b>	
<p><b>A.</b> Drill 2 or 2-1/8" hole through door face as marked for lockset. It is recommended that holes be drilled from both sides to prevent splitting.</p> <p>2" OR 2-1/8" HOLE</p>	<p><b>B.</b> Drill 31/32" or 1" hole in center of door edge for latch. Check template for correct size for your latch application.</p> <p>31/32" OR 1" HOLE</p>	<p><b>C.</b> Match screw holes on strike with center line on jamb. Outline outside edges of strike. Chisel 1/16" deep for strike.</p>	<p><b>D.</b> Install strike and tighten screws. Adjustable lang on strike permit bending in or out to eliminate too loose fit between door and door stop when a strike box is required mount under strike as shown.</p>
<b>3. INSTALL LATCH</b>		<b>5. INSTALL INTERIOR MECHANISM</b>	
<p><b>A.</b> Insert latch in hole keeping it parallel to face of door. Mark outline and remove latch.</p>	<p><b>B.</b> Chisel 1/8" deep or until latch face is flush with door edge.</p>	<p><b>A.</b> Insert knob with spindle into latch making certain that stems are positioned correctly through latch holes. Press flush against door.</p> <p>SPINDLE LATCH HOLE STEMS</p>	<p><b>A.</b> Install interior knob and rose by placing on spindle and aligning screw holes with stems. Push flush against the door, insert screws and tighten until lockset is firm.</p> <p>STEMS SCREW HOLES SPINDLE</p>
<p><b>C.</b> Insert latch and tighten screws.</p>	<p><b>D.</b> Note for drive in latch DRILL HOLE size indicated on template and PRESS latch until it is flush with door edge.</p>		

# DOOR LOCKS

LISABON



## Installation Guide

9807

Print at actual size

**DO NOT INSTALL LEVERS IN METAL DOORS  
NO INSTALAR EN PUERTAS METALICAS**

Suitable for door thickness:  
1-3/8" (35mm) to 1-3/4" (50mm)

